

COOKTOP PARTS
For Model: SF111PXSQ2
(Designer White)

30" GAS FREESTANDING STANDARD CLEAN RANGE ELECTRONIC IGNITION



Illus. Part No. No.	DESCRIPTION	Illus No		DESCRIPTION	Illus.	Part No.	DESCRIPTION
98015589 W10106860 98007130	Literature Parts Instructions Installation Installation Instr (Template) Guide, Use & Care Safer Cooking Tips Tech Sheet	2 3 4 5 6 7 8	98006102 98007225 98013747 98004722	Panel, Manifold Knob, Burner (4)	9 10 11 12 13 14	98005000 98017465 8534079 98008321	Bumper, Cooktop Screw (3) Cap, Burner (4) Screw Knob, Oven Burner, Top (4)


BACKGUARD PARTS
For Model: SF111PXSQ2
(Designer White)



Illus No.	. Part No.	DESCRIPTION
1		Endcap
	98005336	White Left
	98005337	White Right
2	98006083	Rear, Backguard
3	98006393	Swtich, Rocker
4	98017735W	Panel, Backguard
5	9757609	Nameplate
7	98015526	Screw

MANIFOLD PARTS

For Model: SF111PXSQ2 (Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MANIFOLD PARTS


For Model: SF111PXSQ2 (Designer White)

Illus	. Part	
No.	No.	DESCRIPTION
1	98017323	
2	98017582	Venturi, Front (2)
3	98017741	Brkt., Venturi (4)
4	98017359	Venturi, Rear (2)
5 6	98017954 98007411	Spark Module
7	98007411	Regulator Cover, Module
8	98015099	Spreader, Flame
9	98006632	Screw
10	98012138	Burner, Oven
11	98006633	Screw
12	98014545	Harness, Switch
13	98014893	Valve, Oven
14	98006633	Screw
15	W10141709	Valve, Burner (4)
16	98017517	Bolt, Valve Mtg
17	98017558	Pipe, Manifold U–Nut
18 19	98009179 98003984	Thermostat, Oven
19	98005663	Bolt, T–Stat Mtg
20	98017348	Orifice (4)
21	98005652	Igniter, Oven
		Öven Pilot)
22	98017516	Bracket, Valve (4)
23	98007428	Tubing (Regltr to
		Oven Valve)
24	98013314	Locator, Burner
25	98007410	Bracket, Regulator
26 27	98007431 98013634	Fitting 3/8to9/16 Screw
28	1180823	Screw
29	98005663	Screw (2)
30	98017171	Tubing, Inlet
31	98005659	Screw
32	W10146346	Screw
33		Igniter, Top
	W10127480	LF
	W10127479	RR & RF
0.4	W10127481	LR Clin Invitor
34	98015032	Clip, Igniter
	FOLLOW	VING PARTS

FOLLOWING PARTS NOT ILLUSTRATED

W10032010 LP Spud Kit (For Use With LP)

CHASSIS PARTS



CHASSIS PARTS
For Model: SF111PXSQ2
(Designer White)


Illus No.	. Part No.	DESCRIPTION
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 24 25 26 27 29 30 31 33 34 33 34 34 35 36 36 37 37 37 37 37 37 37 37 37 37 37 37 37	98003799 98013690 W10164112 98010042 98005502 98006710 98006739 W10166434 W10153610 W10058460 98004449 W10164109 98003847 98003830 98012175 98005642 98017162 98009179 W10155121 98015100 98017163 98006633 98007126 98006632 98006715 98007191 98014532 98005026 98015346 98006634 98004452 98004451	Flue Box Clip, Flue Shield, Insulation Panel, Side (2) Clip, Oven Bottom Counterweight Wire, Brick Frame, Front Foot, Front (2) Foot, Rear (2) Bottom, Oven Baffle, Side (2) Baffle, Base Rail, Base (2) Support, Burner Clip, Bulb (2) Gasket, Broil Door U-Nut Screw (4) Back, Main Seal, Oven Screw Base, Foot Screw Shield, Channel Shield, Lower Cord, Power Clip, Tubing Foil, Side (2) Screw Top, Oven Side, Oven Right Hand Left Hand
35	98013777	Back, Oven
36	98015363	Support, Rear
37	98004498	Bulb, Light
38	W10114530	Socket, Light
39	98008545	Screw (4)
40	98007205	Cap, Insulation
41	98014105	Cover, Valve
42	98014104	Cover, Socket

INSULATION

W10137227 Insulation, Wrap W10137233 Insulation, Back

OVEN & BROILER PARTS


For Model: SF111PXSQ2 (Designer White)



Illus No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1 2 3 4 5 6	98003480 98016005 98016570 98004761	Rack, Oven (2) Grill, Broiler Pan, Broiler Rack, Broiler Bracket, Rack (2) Guide, Rack(4)	8 9 11	98006727 W10162115 W10137230	Hinge, Brlr Door Screw Liner, Door Insulation, Door Panel, Door	14 15 16	98004052 98006633 98004219	

DOOR PARTS

For Model: SF111PXSQ2 (Designer White)



Illus. Part No. No.	DESCRIPTION	IIIus No		DESCRIPTION	Illus.	. Part No.	DESCRIPTION
3 98010182 4 W10137238 5 98004952 98004953 6 98017875 7 98017767W 8 98017961W	Screw (2) Liner, Door Insulation, Door Clip, Glass Left	10 11 12 13 14 15	98010557 98004993 98016787W	Side Trim, Door(2) White Left White Right Screw Retainer Right	16 17 18 19 20 21	98004219 98004227 98004938 98012904	

OPTIONAL PARTS (NOT INCLUDED)

For Model: SF111PXSQ2 (Designer White)

Illus. **Part**

No. No. DESCRIPTION

Following Parts Not Illustrated

SPLICING WIRES--25FT.

LENGTH

242828 Wire, Black 12 Ga. 150° c 8316781 Wire, Black 14 Ga. 150°c 242821 Wire, Blue 14 Ga. 150°c 242822 Wire, Brown 14 Ga. 150°c 242830 Wire, Brown 14 Ga. 200°c 242823 Wire, Green 14 Ga. 150°c 242824 Wire, Orange 14 Ga. 150°c 242825 Wire, Red 14 Ga. 150°c 242831 Wire, Red 14 Ga. 200°c

242827 Wire, Yellow

14 Ga. 150°c

Illus. Part

No. No. DESCRIPTION

REFINISHING MATERIAL

799832 Kit, Porcelain Repair (White)

242756 Touch-Up

Self-Clean(1/2 Pt)

261582 Grease

INSULATION

261514 Insulation, Fiberglass (1-1/2" x 24" x 120") 240132 Insulation,

Fiberglass (2-1/2" x 22" x 120")

PAINT, TOUCH-UP (1/2oz.)

72017 White 4392899 Biscuit 511873 White Porcelain (2 Oz.)

Illus. Part

No. No. DESCRIPTION

WIRING HARNESS PARTS

6610437 Harness, Control

98005896 Clip, Wire

3196696 Clip, Wire

3391018 Cable Tie-Push Mnt

98015022 Bushing, Snap (2)

98005894 Clamp, Cord

PAINT, PRESSURIZED SPRAY (12 oz.)

350930 White

4392901 Biscuit

285006 Superior Black

206922 Primer (White)

PAINT, BULK (1 qt.)

799344 White (Uncut) 4392900 Biscuit (Uncut)

ANTI-TIP KIT

98017833 Anti-Tip Kit